




ACE PNEUMATICS PVT. LTD.

INNER
ASSY

ACE 240S ROCK BREAKER

PARTS LIST



SR.NO.	PART NO.	DESCRIPTION	QTY.
01	2401001	BACKHEAD	01
02	2401002	CHARGING VALVE	01
03	2401003	O-RING	02
04	2401004	RETAINER	01
4A	2401004A	DUSR SEAL	01
4B	2401004B	U-PACKING	01
4C	2401004C	BUFFER SEAL	01
05	2401005	O-RING	01
06	2401006	PISTON	01
07	2401007	SOCKET PLUG	01
08	2401008	O-RING	01
09	2401009	O-RING	01
10	2401010	O-RING	01
11	2401011	VALVE PLUG	01
12	2401012	VALVE	01
13	2401013	VALVE SLEEVE	01
14	2401014	CYLINDER	01
15	2401015	O-RING	02
16	2401016	ADAPTOR	02
17	2401017	O-RING	02
18	2401018	UNION CAP	02
19	2401019	AIR CHUCK VALVE	01
20	2401020	FRONT HEAD	01
21	2401021	HALLOW HEX	01
22	2401022	STOP PIN	02
23	2401023	RUBBER RING	02
24	2401024	ROD PIN	02
25	2401025	FRONT HEAD PIN	02
26	2401026	RUBBER PLUG	02
27	2401027	INNER BUSH	01
28	2401028	FRONT BUSH	01
29	2401029	CHISEL	01
30	2401030	NUT	04
31	2401031	THROUGH BOLT	04
32	2401032	WASHER	04
33	2401033	NUT	04




ACE PNEUMATICS PVT. LTD.

PARTS LIST

OUTER ASSY

ACE 240S ROCK BREAKER



SR.NO.	PART NO.	DESCRIPTION	QTY.
01	2401034	BRACKET HOUSING	01
02	2401035	UPPER DAMPER	01
03	2401036	WINDOW COVER	01
3A	2401036A	WINDOW COVER	01
04	2401037	HEX BOLT	06
05	2401038	WASHER	06
06	2401039	HOSE BELLOWS	02
07	2401040	SOUND PLUG	04
08	2401041	SOUND PLUG	04
09	2401042	SOUND PLUG	02
10	2401043	DAMPER BOTTOM	01
11	2401044	DAMPER PAD	5
12	2401045	SUPPORT BRACKET	01
13	2401046	SUPPORT BOLT	01
14	2401047	WASHER	02
15	2401048	NUT	02
16	2401049	WEAR PLATE	02
17	2401050	MOUNTING BRACKET	01
18	2401051	BRACKET PIN	02
19	2401052	BRACKET BUSH	04
20	2401053	BRACKET BOLT	12
21	2401054	BRACKET NUT	12